



## Dostupnost aplikace Interaktivní TV na chytrých televizorech

### SAMSUNG

Rok výroby	Skupina	Modelová řada
2019	19TV_PREMIUM	QNZ75C, QNZ75F, QNZ7C, QNZ7F, QRQ60, QRQ70, QRQ80, QRQ90, QRQ60, QRQ70, QRQ80, QRQ90, RQ750, UNU8000, URU8000, URU8000
	19TV_STANDARD	UNU7100, UNU7300, URU7100, URU7300, URU7100, URU710D, URU7300, URU730D, URU7400, URU7410, URU7450, URU74A0, URU750, URU750
2018	18TV_PREMIUM	QNZ9S, QNZ9F, QNZ8FB, QNZ8F, QNZ8C, QNZ7FH, QNZ7F, QNZ7C, QNZ75F, QNZ75C, QNZ6FK, QNZ6F, QNZ65FB, QNZ65F, UNU850D, UNU8500, UNU80A0, UNU800D, UNU8000, UNU76A0, UNU7500, UNU74A0, UNU7450, UNU7400, ULS03NU
	18TV_STANDARD1	UNU730D, UNU7300, UNU710D, UNU7100, UNU7103
	18TV_STANDARD2	UNU7120, UNU709D, UNU7090, UNU6950
	18TV_STANDARD3	UN5510, UN5500, UN5350, UN5300, UN4500, UN4350, UN4310, UN4300
2017	17TV_PREMIUM	UMU9000, UMU8000, UMU7500, UMU70A0, UMU7000, UMU66A0, UMU6500, UMU64A0, UMU6470, UMU6400, UMQS9, UMLS003, QMS9Y, QMQ9F, QMQ8C, QMQ7FD, QMQ7F, QMQ7C, UMUF31E, UMU6000, UMU6100, UMU6300, UMU6310, UMU6320, UMUF30E
	17TV_STANDARD	UM6300, UM5600, UM5520, UM5510, UM5500, UM5300, UM4500
2016	16TV_PREMIUM	UKS9800, UKS9500, UKS9000, UKS8500, UKS8000, UKS7500, UKS7000, UKU66A0, UKU6510, UKU6500, UKU64A0, UKU6400
	16TV_STANDARD1	UKU630D, UKU6300, UKU6000
	16TV_STANDARD2	UK6300, UK6250, UK6200, UK5600, UK5520, UK5510, UK5500, UK5300, UK4300
2015	15TV_PREMIUM	UJS9000, UJS9500, UJS9800, UJS9900
	15TV_STANDARD1	UJU5900, UJU5910, UJU5920, UJU8000, UJU7800, UJU7500, UJU7000, UJS8500, UJS8000, UJU6900, UJU6410, UJU6400, UJU6300, UJS6900, UJU6390, UJU6000, UJU6100, ULS001U, US9A, UJU6800, UJU6740, UJU6700, UJU6600, UJU6510, UJU6500, UJS8600, UJS6700, UJU7090
	15TV_STANDARD2	UJ6400, UJS6000, UJ6330, UJ6300, UJ6240, UJ6200, UJ5520, UJ5510, UJ5500, UJ5300, TE390S, ULS001F, ULS001H, US9F